Your mobile



Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only headphones recommended by TCT Mobile Limited and its affiliates.



(1) Depending on your network operator.

Messages 🔀

From the main menu select "Messages" to create text/multimedia

message. You can type a message but you can also modify a predefined

message in **Templates** or customise your message by adding pictures,

From the main screen, select the icon menu 🧆 and select the

function of your choice in order to customise your telephone:

Tools ==

Color, Theme, Display, Clock, Keys, More settings...

6.1 Create message

Templates

I.I Keys

Navigation key

Pick up

Send a call

Left softkey

Right softkey

In Edit mode

From main screen

In edit mode:

Short keypress: #

Return to the main screen

Access your voicemail (long keypress)

- Long keypress: enter zero

- Short keypress: - (space)

- Long keypress: add a word

Short keypress: access the language list

- Short keypress: change input methods

- Long keypress: access the Symbols table

- Long keypress: activate/deactivate the vibrator

Confirm an option (press the middle of the key)

Access "Varied wallpaper" (long keypress)

Access call memory (Redial) (short keypress)

8.3 Calculator Hold down the 2 # key to get the decimal point. Confirm with the OK key or the left softkey.

Unit converter and Currency converter.

photos, sounds, titles, etc (only available while editing a MMS). While **Voice memo**

writing a message, select "Options" to access all the messaging This feature enables you to record a call by selecting "Voice memo" options. You can save your messages that you send often to **Drafts** or while communicating. To record a sound, select "**Voice memo**", then "New record".

8.6 Memory status My settings...... 🕥

It will indicate how much space is used and how much is currently free

8.7 My shortcuts

Access the shortcuts already programmed. To programme new shortcuts: select "My shortcuts" if you want to create a quick access to a function, Directory, or WAP Bookmarks, etc.



Access Wap options: Homepage, Bookmarks, Recent pages, Offline pages, Go to URL and Profiles.

Main screen icons

- Battery charge level.
- Vibration alert: your phone vibrates, but neither rings nor beeps except for the alarms.
- Headset connected
- Call forwarding activated: your calls are forwarded.
- Alarm clock programmed.
- Voicemail message arrived Switch on/Switch off the telephone (long keypress)
 - FM radio is on
 - Unanswered calls
 - WAP alerts (1)
 - Roaming
 - Line switching (1); indicates the selected line
 - GPRS active connection status (Blue Activated)
 - Shown only in no ciphering mode while calling, sending/ Inserting and removing the SIM Card receiving SMS.
 - Level of network reception
 - Reception of a message in progress
 - Sending a message
 - Silence mode: your phone neither rings, beeps nor vibrates except for the alarms

 - Message list is full: your terminal cannot accept any new messages. You must access the message list and delete at least 2.2 Power on your phone one message on your SIM card.
 - Preferred tariff areas (1).
 - Antenna off mode

Depending on your network operator

Getting started

2.I Set-up

Removing and installing the back cover



Installing and removing the battery





Place the SIM card with the chip facing downwards and slide it into its During a call, you can use your directory, your diary, short messages, housing. Make sure that it is correctly inserted. To remove the card, etc. without losing your correspondent by pressing the 🔸 key. press it and slide it out.

Games

It allows you to manage settings, in which you may set background

Your phone is equipped with an EM radio (1) with RDS functionality You

and saved channels or with parallel visual information related to the

radio program on the display, if you tune to stations that offer Visual

Your mobile phone is fitted with a camera for taking photos that you

- send them in a multimedia message (MMS) to a mobile phone or

- select them as incoming call image to a contact in your directory.

Radio service. You can listen to it while running other applications.

FM radio 🏣

Camera 10

Hold down the we key until the phone powers on.

2.3 Power off your phone

II.I Game settings

Hold down the weight key from the main screen.

3.1 Making a call

Dial the desired number then press the $\$ key to place the call. If You can access your call memory by pressing the $\$ key from the you make a mistake, you can delete the incorrect digits by pressing the main screen. right softkey

To hang up the call, press the 🚧 key.

Making an emergency call

If your phone is covered by the network, dial emergency number and GPRS counter, Beep duration. press the \(\subseteq \text{ key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the 4.3 Call settings keypad.

3.2 Calling your voicemail (1)

To access your voicemail, hold down the | w key.

3.3 Receiving a call

When you receive an incoming call, press the \(\subseteq \text{key to talk and} \) then hang up using the 💜 key.

3.4 Available functions during the call

Calls Call register

4.I Call memory

4.2 Billing

You can access different items with this option: Amount, Duration

You can access a number of items with this option: Call waiting, Call forwarding, Call barring, Caller ID, Line switching, Auto redial.

Directory.....

Consulting your directory

To access the **directory** from the main screen, press the OK key and select the icon from the menu.

5.2 Creating a file

Select the directory in which you wish to create a file, press the "Options" softkey, select "Create file" then OK.

(1) Contact your network operator to check service availability

Profiles.....

With this menu, you may personalise ringtones for different events and

5 Latin input mode

To write messages, there are two writing methods:

- Normal: this mode allows you to type a text by choosing a letter or a sequence of characters associated with a key. Press the key several times until the desired letter is highlighted. When you release the key the highlight character is inserted into the text.
- can use the application as a traditional FM radio with automatic tuning Predictive with the Zi mode: this mode speeds up the writing of your text. Write the word by pressing a key between and ≥ ∞ and 9. Press the key once and the word will be modified each time you press a key. As you go on, the word will keep changing. Example: For "Tomorrow", press on the following keys: 8 TUV, mno 6, $\text{mno} 6 = \text{Too} \rightarrow \text{mno} 6 \rightarrow \text{tomorrow}$
 - + key in edit mode Short keypress; access the language list Long keypress: enter zero

ALCATEL is a trademark of Alcatel-Lucent and used under license by TCT Mobile Limited.

All rights reserved © Copyright 2009 TCT Mobile Limited.

TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.

🚺 File manager...... 🚞

You will have an access to all audio and visual files stored in phone in Your Alcatel phone may include some games. File manager.

10.1 My audios

Choose an audio for an incoming call, a message alert, power on/off music, sound effect and vibration alert. ringtone or an alarm and scheduler.

10.2 My images

You can select an image or a photo as wallpaper or the ON/OFF

10.3 My creations

This feature stores all the photos captured by your mobile phone.

10.4 Unknown files

Store files of unsupported format

10.5 Formats and compatibility

- Sounds: midi_amr

(1) The quality of the radio depends on the coverage of the radio station in that particular area.

English - CJB30M0ALAAB 12

8.2 Alarm

Your mobile phone has a built-in alarm clock with a snooze feature.

Once you enter this menu from "Tools", there is a monthly-view

calendar for you to keep track of important meetings, appoi etc. Days with events entered will be marked in color

8.1 Organizer

can use in different ways:

an email address.

- customise your main screen.

- store them in your "File manager"

manufacturer disclaims any liability for damage, which may result as a consequence temporary and not serious. of improper use or use contrary to the instructions contained herein.

TRAFFIC SAFETY:

a real risk, even when the hands-free kit is used (car kit, headset...), drivers are jested to refrain from using their mobile when the vehicle is not parked.

When driving do not use your phone and headphone to listen to music or to the Use only batteries, battery chargers, and accessories which are recommended by radio. Using a headphone can be dangerous and forbidden in some areas.

the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure use of other chargers or batteries. that there is no problem:

- do not place your phone on top of the dashboard or within an airbag deployment
- check with your car dealer or the car manufacturer to make sure that the dashboard is adequately shielded from mobile phone RF energy.

CONDITIONS OF USE:

Switch the phone off before boarding an aircraft.

signs and instructions posted in a fuel depot, petrol station, or chemical plant, or in any potentially explosive atmosphere.

When the phone is switched on, it should be kept at least 15 cm from any medical - Play at the farthest distance possible from the screen. device such as a pacemaker, a hearing aid or insulin pump, etc. In particular when using the phone, you should hold it against the ear on the opposite side to the device, if any.

To avoid hearing impairment, pick up the call before holding your phone to your ear. Also move the handset away from your ear while using the "hands-free" mode because the amplified volume might cause hearing damage. Do not let children use the phone and/or play with the telephone and accessories

without supervision When replacing the cover please note that your phone may contain substances that

could create an allergic reaction.

Always handle your phone with care and keep it in a clean and dust-free place.

Do not allow your phone to be exposed to adverse weather or environmental • PRIVACY: manufacturer's recommended operating temperature range is -10°C to +55°C. We recommend that you read this chapter carefully before using your phone. The Over 55°C the legibility of the phone's display may be impaired, though this is

> Emergency call numbers may not be reachable on all cellular networks. You should never rely only on your phone for emergency calls.

Do not open, dismantle or attempt to repair your mobile phone yourse

TCT Mobile Limited and its affiliates and are compatible with your phone model). When switched on, your phone emits electromagnetic waves that can interfere with TCT Mobile Limited and its affiliates disclaim any liability for damage caused by the • BATTERY:

> Remember to make back-up copies or keep a written record of all important switched off. information stored in your phone.

Some people may suffer epileptic seizures or blackouts when exposed to flashing - Do not attempt to open the battery (due to the risk of toxic fumes and burns). lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your You are advised to switch off the telephone from time to time to optimise its doctor before playing video games on your phone or enabling a flashing-lights feature Batteries must be disposed of in accordance with locally applicable environmental on your phone.

Switch the phone off when you are in health care facilities, except in designated incorporate flashing lights on the phones. All persons should discontinue use and affiliates. areas. As with many other types of equipment now in regular use, mobile telephones consult a doctor if any of the following symptoms occur: convulsion, eye or muscle can interfere with other electrical or electronic devices, or equipment using radio twitching, loss of awareness, involuntary movements, or disorientation. To limit the elihood of such symptoms, please take the following safety precautions:

- Switch the phone off when you are near gas or flammable liquids. Strictly obey all Do not play or use a flashing-lights feature if you are tired or need sleep. Take a minimum of a 15-minute break hourly.
 - Play in a room in which all lights are on.

 - If your hands, wrists, or arms become tired or sore while playing stop and rest for several hours before playing again.
 - If you continue to have sore hands, wrists, or arms during or after playing, stop the game and see a doctor.

When you play games on your phone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow the instructions to avoid problems such as tendinitis, carpal tunnel syndrome, or other musculoskeletal disorders



Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only headphones the listener's hearing. Set your phone volume safely. Use only headphones the listener's hearing. Set your phone volume safely. Use only headphones the listener's hearing. Set your phone volume safely. Use only headphones the listener's hearing. Set your phone volume safely. Use only headphones the listener's hearing. Set your phone volume safely. Use only headphones the listener's hearing. Set your phone volume safely. Use only headphones the listener's hearing. Set your phone volume safely. Use only headphones the listener's hearing. Set your phone volume safely. Use only headphones the listener's hearing. Set your phone volume safely. Use only headphones the listener's hearing. Set your phone volume safely. Use only headphones the listener's hearing. Set your phone volume safely. Use only headphones the listener's hearing. Set your phone volume safely. Use only headphones the listener's hearing. Set your phone volume safely. Use only headphones the listener's hearing set your phone volume safely. Use only headphones the listener's hearing set your phone volume safely. Use only headphones the listener's hearing set your phone volume safely. Use only headphones the listener's hearing set your phone volume safely. Use only headphones the listener's head the listener's hearing set your phone volume safely. Use only headphones the listener's head the listene

record the voices of other people or any of their personal attributes, and duplicate not work in another jurisdiction. They should be used for this purpose only. or distribute them, as this may be considered to be an invasion of privacy. It is the • RADIO WAVES:

Observe the following precautions for battery use:

- Do not puncture, disassemble or cause a short-circuit in a battery.
- Do not burn or dispose of a used battery in household rubbish or temperatures above 60°C.

regulations. Only use the battery for the purpose for which it was designed. Never age or state of health. Parents should monitor their children's use of video games or other features that use damaged batteries or those not recommended by TCT Mobile limited and/or its. The exposure standard for mobile phones is determined by a measurement unit



This symbol on your telephone, the battery and the accessories means that these products must be taken to collection points at the end of

- Municipal waste disposal centres with specific bins for these items of
- Collection bins at points of sale. They will then be recycled, preventing substances being

environment, so that their components can be reused. In European Union countries:

These collection points are accessible free of charge All products with this sign must be brought to these collection points.

In non European Union jurisdictions:

Items of equipment with this symbol are not to be thrown into ordinary bins if you jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled. Prolonged exposure to music at full volume on the music player may damage CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT

isdiction or other jurisdiction(s) where you will use your mobile phone regarding. The chargers designed for your mobile phone meet with the standard for safety of the SAR levels on various phones and at various positions, they all meet the relevant taking photographs and recording sounds with your mobile telephone. Pursuant to information technology equipment and office equipment use. Due to different International guidelines and EU requirements for RF (radio-waves) exposure. such laws and regulations, it may be strictly forbidden to take photographs and/or to applicable electrical specifications, a charger you purchased in one jurisdiction may. The World Health Organisation (WHO) considers that present scientific

Directive 1999/5/EC (R&TTE) is required of all mobile phone models before they can keep mobile phones away from the head and body (fact sheet n° 193). Additional be put on the market. The protection of the health and safety for the user and any other person is an essential requirement of these standards or this directive. THIS MOBILE PHONE COMPLIES WITH INTERNATIONAL AND EUROPEAN Although no danger relating to the use of telephone was ever proved, the World

international requirements (ICNIRP) (1) and by the Council of the European Union of pregnant women and from the lower abdomen for teenagers.

REQUIREMENTS REGARDING EXPOSURE TO RADIO WAVES.

These limits are part of a set of requirements and establish authorised avoid touching it or degrading it. radiofrequency levels for the public. These limits were established by independent . LICENCES groups of experts on the basis of regular and detailed scientific assessments. They include a significant safety margin intended to ensure the safety of all, regardless of Obigo®

known as the Specific Absorption Rate or "SAR". The SAR limit is set by international requirements or by the Council of the European Union at 2 watts/kilogram (W/kg) averaged over 10 grams of body tissue. The tests used to determine SAR levels were arried out on the basis of standard usage modes with the phones transmitting at heir maximum power level over the entire range of frequency bands.

Although the SAR was established at the highest certified level, the actual SAR level for the mobile phone during use is generally much lower than the maximum values. In fact, since mobile phones are designed to operate at many different power levels. they only use the minimum level of power required to provide a connection to the network. In theory, the closer you are to a base station antenna, the lower the power level required by the mobile phone.

- The ICNIRP requirements are applicable in the following regions Central America (except Mexico), South America, North and South Africa Pacific Asia (except Korea) Australia
- The European recommendation (1999/519/EC) is applicable in the following regions: Europe, Israel,

The highest tested SAR value for this mobile phone for use at the ear and

information does not indicate the need for any special precautions for use of mobile phones. If individuals are concerned, they might choose to limit their own or their Proof of compliance with international standards (ICNIRP) or with European children's RF exposure by limiting the length of calls, or using "hands-free" devices to

On our Internet site, you will find our FAQ (Frequently Asked information about electromagnetic fields and public health are available on the following site: http://www.who.int/peh-emf.

Health Organisation advises as a precautionary measure to use your telephone with Before removing the battery from your phone, please make sure that the phone is Your mobile phone is a radio transmitter/receiver. It was designed and manufactured a good level of network reception as indicated on the telephone display (4 to 5 bars). to comply with the radiofrequency (RF) exposure thresholds recommended by It is also advised to keep the telephone, during communications, away from the belly

Your telephone is equipped with a built-in antenna. For optimal operation, you should

is a registered trademark of Obigo AB.

eZiText™

eZiText™ and Zi™ are trademarks of Zi Corporation and/or ZICOrporation its Affiliates.

General information

- Internet address: www.alcatel-mobilephones.com
- Hot Line Number: see "TCT Mobile Services" leaflet or go to our Internet site

Questions) section. You can also contact us by e-mail to ask any questions you may have

An electronic version of this user guide is available in English and other languages according to availability on our server; www.alcatel-

Your telephone is a transceiver that operates on GSM networks with 900 and 1800 MHz bands

This equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The entire copy of the Declaration of Conformity for your telephone can be obtained through our website: www.alcatel-mobilephones.com.

Protection against theft (1)

Your telephone is identified by an IMEI (phone serial number) shown on the packaging label and in the product's memory. We recommend that you note the number the first time you use your telephone by entering * # 0 6 # and keep it in a safe place. It may be requested by the police or your operator if your telephone is stolen. This number allows your mobile telephone to be blocked preventing a third person from using it, even with a different SIM card.

Disclaimer

There may be certain differences between the user manual description and the phone's operation depending on the software release of your telephone or specific operator services

(i) Contact your network operator for service availability

Telephone warranty

Congratulations on choosing this mobile phone - we hope that you will be completely satisfied with it.

Your phone is guaranteed against any deviation from technical specifications for a period of twelve (12) months from the date specified on your original invoice, subject to any other specific 5) connecting to or integrating into the phone any equipment not • You are advised to fully charge (iii), the battery for optimal provisions (

The warranty terms defined in the manual also apply to the battery and accessories sold with the phone but for a period of six (6) months 6) any servicing, modification or repair performed by individuals not (2) from the date of purchase shown on your original invoice.

Under the terms of this warranty you must immediately inform your vendor (or any repair centre approved by TCT Mobile Limited or its affiliates, which are listed on our website http://www.alcatelmobilephones.com) in case of a conformity defect on your phone, and 8) normal wear, present the invoice given to you at the time of purchase. The vendor or repair centre will decide whether to replace or repair, as appropriate, all or any part of the telephone or accessory found to be 10) modifications made to the equipment even if required by changes My phone has not responded for several minutes defective; this warranty covers the cost of parts and labour but excludes any other costs. Repair or replacement may be carried out 11) faulty connections resulting from unsatisfactory radio transmission using reconditioned components offering equivalent functionality.

Servicing under the terms of this warranty, especially repair, modification or replacement of products, shall entitle to a ONE (1) month warranty unless there are statutory provisions to the contrary. This warranty shall not apply to damage or defects to your mobile In accordance with the applicable law, your product is warranted phone and/or accessory caused by:

- 1) not following the instructions for use or installation,
- provisions are applicable in your jurisdiction
- 200 more recharges.

2) not being compliant with technical and safety standards applicable **Troubleshooting......** in the geographical area where the equipment is used,

- 3) improper maintenance of sources of energy, and of the overall electric installation
- accidents or consequences of theft of the vehicle in which the infiltration of liquids inclement weather
- supplied or not recommended by TCT Mobile Limited or its affiliates without their express written consent for such authorised by TCT Mobile Limited or its affiliates, the vendor or
- the approved maintenance centre 7) use of the mobile phone and/or its accessory for a purpose other My mobile phone will not switch on
- than that for which it was designed.
- malfunctions caused by external causes (e.g., radio interference from other equipment, power voltage fluctuations).
- in regulations and/or modification of network parameters.
- or caused by the absence of radio relay coverage. 12) equipment on which markings or serial numbers have been removed or altered, and handsets on which labels have been
- removed or deteriorated shall be excluded from the warranty. against hidden defects (defects inherent in the design, manufacture, My mobile phone turns off by itself

There are no express warranties, whether written or oral, other than (i) The mandatory warranty period may vary if overriding statutory this printed limited warranty, express or implied, of any nature whatsoever

The life of a rechargeable mobile phone battery in terms of In no event shall TCT Mobile Limited or its affiliates be liable for conversation time, standby time, and total service life, will depend incidental or consequential damages of any nature whatsoever, on the conditions of use and network configuration. Batteries including but not limited to trading loss, commercial loss, to the full being considered expendable supplies, the specifications state that extent those damages can be disclaimed by law. Some countries/states you should obtain optimal performance for your mobile phone do not allow the exclusion or limitation of incidental or consequential during the first six months after purchase and for approximately damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

Before contacting the aftersales department, you are advised to follow

- telephone is transported, acts of vandalism, lightning, fire, humidity. You are advised to switch off the telephone from time to time to optimise its performance
 - operation
 - Avoid storing large amounts of data in your telephone as this may affect the performance of your telephone.

and carry out the following checks:

Press until the screen comes on

- Check the battery charge level
- Check the battery contacts, remove and reinstall your battery, then turn your telephone back on

- Remove the battery and re-insert it, then switch the phone back on

My screen is difficult to read

- Clean your screen
- Use your mobile phone in accordance with the recommended conditions of use

- Check that your keypad is locked when you are not using your
- Check the battery charge level

My mobile phone has a low level of autonomy

- hours) After a partial charge, the battery level indicator may not be exact.
- Wait for at least 20 minutes after removing the charger to obtain an exact indication

My mobile phone will not charge properly

- Make sure that your battery is not completely discharged; the The caller's name does not appear when a call is received accompanied by a quiet whistling sound
- Make sure charging is carried out under normal conditions (0°C The sound quality of the calls is not optimal +40°C) • Make sure your battery is inserted. It must be inserted before
- plugging in the charger Make sure you are using an Alcatel battery and charger
- When abroad, check that the electrical current is compatible

My mobile phone will not connect to a network

- Try connecting in another location
- Verify the network coverage with your operator Check with your operator that your SIM card is valid
- Try selecting the available network(s) manually

Try connecting at a later time if the network is overloaded

SIM card error

- Make sure the SIM card has been correctly inserted
- Verify with your operator that your SIM card is 3V compatible: the old 5V SIM cards cannot be used
- Make sure the chip on your SIM card is not damaged or scratched

Unable to make outgoing calls

- Make sure you have dialled a valid number and press the
- For international calls, check the country and area codes. • Make sure your mobile phone is connected to a network, and that
- the network is not overloaded or unavailable Check your subscription status with your operator (credit, SIM card valid etc)
- · Make sure you have not barred outgoing calls

Unable to receive incoming calls

- Make sure you respected the complete charge timing (minimum 3 Make sure your mobile phone is switched on and connected to a Make sure your operator's voicemail number is correctly entered in
 - network (check for overloaded or unavailable network) Check your subscription status with your operator (credit, SIM card valid, etc.)
 - Make sure you have not forwarded incoming calls
 - Make sure that you have not barred certain calls

battery charge indicator can take several minutes and may be • Check that you have subscribed to this service with your operator Your caller has concealed his/her number

- You can adjust the volume during a call by means of the can key
- Check the radio reception icon level
- I am unable to use the features described in the manual
- Check with your operator to make sure that your subscription. includes this service

Make sure this feature does not require an Alcatel accessory When I select a number from my directory, the number is

- not dialled • Make sure that you have correctly recorded the number in your file
- Make sure that you have selected the country prefix when calling a
 Check for free space foreign country

I am unable to create a file in my directory

 Make sure that your SIM card directory is not full; delete some files or save the files in the product directory (i.e. your professional or personal directories)

Check the "Call barring" option for "Incoming calls" to be sure that the "All calls except SIM directory" feature is not activated My callers are unable to leave messages on my voicemail

Contact your network operator to check service availability

I cannot access my voicemail

- "My numbers"
- Try later if the network is busy

I am unable to send and receive messages MMS, Vox MMS

- Check your phone memory available as it might be full.
- · Contact your network operator to check service availability and check MMS parameters
- Verify the server centre number or your MMS profile with your operator
- The server centre may be saturated; try again later

The icon is displayed on my standby screen

You have saved too many short messages on your SIM card; delete some of them or archive them in the product memory

"No service" is displayed

You are outside of the network coverage area

I have already entered 3 incorrect PIN codes

· Contact your network operator to obtain the PUK code (Personal Unblocking Key)

I am unable to download new files

- Check your subscription status with your operator

22 23