

H700 **Bluetooth®** Handsfree Headset



Motorola, Inc. Consumer Advocacy Office 1307 East Algonquin Road Schaumburg, IL 60196

www.hellomoto.com 1-877-MOTORI U 1-888-390-6456 (TTY/TDD United States for hearing impaired)

Guide Number: 6809499A88-O





## **BEFORE YOU BFGIN**

Before using this product, read the Important Safety and Legal Information pamphlet and follow its instructions

Take a moment before you get started to familiarize yourself with your new H700 Headset



PAIR CONTINUED

**Your Phone** 

Step B - SET YOUR PHONE TO LOOK FOR

1 On your Motorola phone, press (Menu) >

The phone lists Bluetooth devices it finds.

3 Select **OK** or **Yes** to pair your headset with

Settings > Connection > Bluetooth Link >

For most Motorola phones:

Handsfree > Look for Devices.

2 Select Motorola H700.

4 Enter the passkey: 0000

steadily lit to flashing blue.

your phone.

YOUR HEADSET





1 Plug the Motorola charger into the end of the headset

The indicator light turns red when the battery is charging. It may take up to 1 minute for the indicator light to turn on. When the headset's battery is fully charged (about 2 hours), the indicator light turns areen.

2 Disconnect the charger.

Note: Headset is not functional while charging.



Your Phone

Your phone's Bluetooth feature is off by default To use your headset, you must turn on the Bluetooth feature in your phone.

For most Motorola phones (at the main menu).

- 1 Press (Menu) > Settings > Connection > Rivetooth Link > Setun.
- 2 Scroll to Power.
- 3 Select Change.
- 4 Scroll to On.
- **5** Press **Select** to turn on the Bluetooth feature. The Bluetooth feature remains on until you turn the feature off.

Note: These steps are for most Motorola phones. For other phones, see your phone's user's quide.



## PAIR Your Headset

Before you can use your headset, you must pair (link) it with your phone.

### Step A - PUT THE HEADSET IN PAIRING MODE

The headset indicator light will be steadily lit in purple when in pairing mode. To place the headset in pairing mode:

- If the headset has never been paired with another device, simply open the headset boom. The indicator light becomes steadily lit in purple.
- If the headset has previously been paired with other devices, first ensure those devices are turned off. Then open the headset boom and the indicator light flashes in blue. After about 5 seconds, the indicator light becomes steadily lit in purple.

If the headset does not enter pairing mode. see TROUBLESHOOTING for help.

**TROUBLESHOOTING** 

My headset will not enter pairing mode.

and wait for 10 seconds. The indicator light

becomes steadily lit in purple indicating the

headset is now in pairing mode.

My phone doesn't find my headset.

Make sure that any devices previously paired

with the headset are turned off. If the indicator

light is flashing in blue, turn off the other device

## **USING YOUR H700**

### Features and **Functions Guide**

on the reverse side for information on using your H700.



## on (lit in purple) and steady when your phone is searching for devices (see step 3).

Make sure the indicator light on your headset is

## My headset worked before but now it's not working.

Make sure your phone is on and the Bluetooth feature is turned on in your phone (see step 2). If the Bluetooth feature was turned off or was turned on only temporarily, you may need to restart the Bluetooth feature (see step 2) and pair your phone and headset again (see step 3).

## Support.

If you need more help, contact us at 1-877-MOTOBLU or visit us at www.hellomoto.com/bluetooth and click Support

# Your phone and headset are now paired

and ready to make and receive calls. To make a call:

- 1 Open the headset boom and place the headset over your ear.
- 2 On the phone, dial the number you want to call and press **SEND** key on your phone.
- **3** If your phone and headset are successfully paired, you will hear ringing on the headset.

After you have successfully paired your phone and headset, you don't need to repeat these steps. For daily use, ensure that your headset is turned ON and that your phone's Bluetooth feature is ON.

To save battery power, turn OFF the headset when you don't use it for an extended time by closing the boom.

**5** Select **OK**. When your headset successfully pairs with your phone, the indicator light changes from

> Note: These steps are for most Motorola phones. For other phones, see your phone's user's guide.

## TEST AND USE

# **Features and Functions Guide**

H700 Bluetooth® Handsfree Headset

IMPORTANT:
Be sure to first follow the
Quick Start Guide
on the reverse side to
complete initial setup of
your H700.

## **TURNING ON AND OFF**

**To turn your headset on**, open the headset boom. The indicator light flashes blue if paired with another device, or is steadily lit in purple if ready to be paired.


**To turn your headset off,** close the headset boom. The indicator light will turn off

To conserve battery power, turn off your headset when you don't plan to use it for



# WEARING THE HEADSET

- 1 Open the headset boom, then open the earhook (45° from the headset).
- 2 Loop the earhook over your ear.
- **3** Press the headset to your ear.
- **4** Point the headset boom towards your mouth.



## CHANGING FOR USE ON OTHER EAR

You can wear your H700 headset on your left or right ear. The headset comes ready for the right ear. To change the headset for the left ear:

- 1 Open the headset boom, then open the earhook (90° from the headset).
- **2** Gently lift and pull the top of the earhook up and off the upper hinge pin. Then, pull it away to remove it.
- **3** Flip the headset over.
- 4 Hook the bottom of the earhook onto the lower hinge pin, then lift and pull the top of the earhook over the upper hinge pin.







hutton

## MAKING CALLS MAKING CALLS CONTINUED

Function		Action
Make a voice dia	al call	Tap the <b>Call</b> button and speak the name after the tone
End a call		Tap the <b>Call</b> button
Receive a call		Open headset boom or tap the <b>Call</b> button (if boom is already open)
Reject a call		Press and hold the <b>Call</b> button until you hear a beep
Redial last call		Press and hold the <b>Call</b> button until you hear a beep

Note: Your H700 supports both Handsfree and Headset Profiles. Accessing call functions depends upon which profile your phone supports. See your phone's user's guide for more information.

Function	Action
Answer a second incoming call	Press and hold the <b>Call</b> button (places first call on hold)
Toggle between two active calls	Press and hold the <b>Call</b> button
Join a 3-way call	Press and hold both <b>Volume</b> button
Put an active call on hold or resume a call on hold	Press and hold the <b>Call</b> button until you hear a beep
Transfer a call from the phone to the headset	Open headset boom
Disable the indicator light	Press and hold both <b>Volume</b> buttons for 3 to 4 seconds
Mute or unmute a call	Tap both <b>Volume</b> buttons

## INDICATOR LIGHTS

With the Charger Plugged In

Headset Status
Charging (less than 80% charged)
Charging (more than 80% charged)
Charging complete

	With No Charger Plugged In		
	Indicator Light	Headset Status	
	Off	Power off	
	Purple (steady)	Pairing mode/ Volume button orientation	
	Red	Battery low	
	Blue (10 rapid flashes)	Pairing successful	
•	Blue (slow pulse)	Connected (on a call)	
	Blue (quick flash)	Standby (not on call)	
	Note: After 5 minutes of ina	ctivity, the light stops flashing	

Note: After 5 minutes of inactivity, the light stops flashing to conserve power, but the headset remains in standby mode.

## **AUDIO TONES**

CHANGING VOLUME

**BUTTON ORIENTATION** 

You can also change the orientation of the

1 Turn the headset power off by closing

purple, then press the **Volume** button

vou want to assign as the "volume up"

volume buttons on your headset.

2 Press the **Call O** button until the indicator light becomes steadily lit in

the headset boom

The audio tones provide information about your headset status.

Audio Ton e	Headset Status
Single high tone when pressing Volume button	Volume at minimum or maximum
Five rapid high tones repeated every 60 sec.	Low battery
No audio indications;	Out of range
deteriorating quality	
Ring tone	Incoming call
Single high tone	Pairing confirmation
Single low tone	Voice activation
Dual high/low tone	Voice tag not recognized
Single high tone	End call
Low to high tone	Phone network not available
Two ascending tones	Mute enabled
Two descending tones	Mute disabled