



Made for iPhone

User Manual - Before using, please read the manual carefully

(


(

Main Features

- Digital clock and alarm clock with independent snooze and dimmer function
- Digital tune FM Radio
- White LCD display with blue back light
- Compatible with most iPods, with an integrated universal dock for charging your iPod
- Last station, volume and function memory
- Stereo speakers
- 3.5mm audio AUX input jack connected to any por table audio device
- 20 station memory presets
- iPhone incoming call alert
- Wake to iPhone/iPod, radio or buzzer

Main Controls

FRONT VIEW



1. ► / /MEM/SET

- Play and pause/Memory/Clock setting

2. POWER

- Power on or off - Mode alternation

3. FUNCTION

4. **◄**◀/T-

- Search-/Last/Backward

5. VOL-/AL MODE

- Volume down /Alarm mode


6. VOL+

- Volume up

7. ▶▶|/T+



SIDE VIEW





1. Built-in quality speaker



TOP VIEW







(

1. DOCK for iPod and iPhone

 $2. \ SNOOZE/SLEEP/LIGHT \quad \ \ - Alarm \ snooze/Sleep \ selecting \ /LCD \ brightness \ adjustment$

3. FM ANT -FM antenna lead

4. -€+ -Power input jack

5. AUX IN -3.5mm auxiliary input jack

Function operation

Power On:

Input DC 5V into the Input Source at the back of the music station, light the display and clock appears, then tap " $^{\prime\prime}$ POWET " lab.

Music Play:

1. IPHONE operation:

The music station will enter to "IPHONE" function directly when power on. Dock iPhone/iPod on the iPod dock, and play the music from iPhone/iPod. (iPod/iPhone can be charged when the main unit connects to power).

Under "IPHONE/IPOD" mode, press " ▶|| " for pause. (Note: there is no " ▶ "or " || "on the LCD when iPhone/iPod" is played or paused, but on the iPhone/iPod itself).

Music selection:

Press " ◄◄/T- "or " ▶▶| /T+"for music selection when iPhone/iPod is played or paused.

Press " ◄◄ /T- "or " ▶▶ /T+" and hold it for backward or forward when iPhone/iPod is played or paused.

iPhone incoming call alert:

When there is an incoming call during iPhone music playing, the music station will stop the music and alternate it into

2. TUNER operation

Manual Tuner or Automatic Tuner:

Press "I◀¶/T-" or "▶▶I/T+" for manual tuner, while press "I◀¶/T-" or "▶▶I/T+" and hold it for two seconds when enter to automatic tuner. The tuner will stop automatically when get access to channels.





Clock Dock Instruction Manual.indd 2-3



Manual channel memory:

When get acess to the channels by manual, press "►I/MEM/SET" and hold for a while. Press "► /T- "or "►►I/T+" to choose the saving location. 20 channles can be memorized and saved.

Memory selection:

Press "►II/MEM/SET" to alternate the memory channel.

3. AUX operation

Select AUX under power on and input the external music source to AUX, turn on volume and the music is ready.

Volume

VOL- and VOL+ can be adjusted within 00-20.

Clock setting:

Under standby mode, press "▶|| /MEM/SET" and hold it into clock setting, then there will be clock shining on LCD. Tap " |◄◄/T- "or "▶▶| /T+" to set "hour" and tap " ▶|| /MEM/SET" to set "minute", then press" ▶|| /MEM/SET"again to confirm the setting and resume to clock mode.

Alarm setting:

Under STAND BY mode, press and hold "VOL-/AL MODE" when there will be time displaying and LCD shinning. Tap " ◄◄/T- " or "▶▶|/T+" to set "hour", and "VOL-/AL MODE" to set "mimute" and then tap "VOL-/AL MODE" again to confirm the setting and return to clock mode.

Alarm mode setting:

Tap " $\blacktriangleleft \top$ " or " $\blacktriangleright \blacktriangleright \top$ /T+" and enter into the alarm setting mode (TONE/IPOD/RADIO). Select the mode and tap "VOL-/AL MODE" to return to clock mode.

SNOO7E

When Alarm rings, press "SNOOZE" to set up snooze function. Then alarm pauses and will ring again in 9 minutes, if press "POWER" at this time, the alarm will stop and terminate.

SLEEP:

Press "SNOOZE/SLEEP/LIGHT" under any mode and then start to set the snooze and select 120M-90M-60M-30M-15M-OFF.

LIGHT:

There are three brightness modes of LCD when the unit is in stand-by.

Specifications:

| Power supply | DC 5V |
|--------------------|----------------------------|
| | AC 100 - 240 V adapter |
| Tuning system FM | 87.5 - 108 MHz |
| Tuning sensitivity | FM < 20 dB |
| Frequency response | 20 Hz - 20 kHz (aux in) |
| S/N Ratio | > 60 dB |
| Audio output | Stereo speaker (1.2 W x 2) |
| Audio input | iPod dock |
| | 3.5 mm auxiliary line in |

Specifications and instructions manual are subject to change without notice.



